

BLUE  TIGER[®]

SOUND. CLEARLY.

User Manual | SoundTRAX[™]

800.935.1165

www.bluetigerusa.com


Thank you for purchasing the SoundTRAX™ by Blue Tiger. Please read through this user manual before using your headset to ensure your best experience.

Product Features

The SoundTRAX™ by Blue Tiger has been designed to provide you with a high quality music and calling experience. Comfortable and fashionable, the SoundTRAX™ will be your companion at home, the gym, or anywhere you are when you want your music with you.

The SoundTRAX™ is equipped with multiple connection options including Bluetooth, microSD, and wired connection. The SoundTRAX™ can last for up to 30 hours of continuous use (up to 400 hours on standby) on a single charge.

Getting Familiar with your SoundTRAX™



Bluetooth® Pairing Instructions

1. Make certain your SoundTRAX™ is in the “Off” position.
2. Move the switch to Bluetooth and then hold down the multi-function wheel for about 8-10 seconds to initiate pairing mode. Upon activating pairing mode, the LED light will flash to blue for a few seconds and then begin flashing blue/red.
3. Follow the operating instructions for your phone to allow your device to search for a new Bluetooth connection.
4. Select the headset from your Bluetooth device list on your phone and when asked, select “Yes” to confirm the connection.
5. If a PIN, Passkey, or Passcode is required, enter “0000.”

If at any time you experience difficulty pairing your headset with your device, Blue Tiger recommends that you turn off the SoundTRAX™ and your phone and if possible, remove the battery from your phone or device. Wait a few seconds and then turn both devices back on and attempt pairing again from step one.

Basic Operation in Bluetooth® Mode

All functions are based on the multi-function wheel

Call Control

Pairing Mode: Press and hold for 5-6 seconds

Voice-Dial: Press and hold for about 2 seconds and wait for phone to respond

Redial: Press 2 times rapidly

Answer/End Call: Press once

Refuse call: Press and hold for 2-3 seconds

Music Playback Control

Volume+: Press and hold “vol+” for two seconds during a conversation or during music playback to increase volume

Volume-: Press and hold “vol-” for two seconds during a conversation or during music playback to decrease volume

Rewind to previous track: Press and release “vol-” when playing music

Skip to next track: Press and release “vol+” when playing music

Play/Pause: Press and release the multi-function wheel

Using the SoundTRAX™ In Wired/SD Mode

Your SoundTRAX™ headset also has the option to bypass

Bluetooth entirely and be used as a wired headset *or* to play

music directly from a microSD card. To do so, simply switch the headset to the “mp3 “ position and plug the included stereo headset cable into the headset and the music playback device or place a microSD card with Mp3 files saved directly to the root directory into the TF/SD card slot. Please note that while in wired mode, the headset will no longer have the ability to control playback functions from a tethered device. These functions will need to be performed by the playback device when the headset is in wired mode.

Understanding the LED Indicator

Red Solid: While charging, indicates that charging is taking place

Blue Intermittent: Flashes 3 times to indicate power on, then 2 times every two seconds indicating operation

Red/Blue Alternating: Indicates pairing mode

Blue Light Flashes 3 Times Rapidly: Indicates a.) Voice dial activated, b.) Redial activated, c.) Volume adjusted, d.) Call answered, e.) Call refused, f.) Call ended.

Battery Care and Best Practices

Please allow your headset to charge for a minimum of 2 hours and a maximum of 4 hours. Leaving the headset on to charge longer than the recommended time could have a negative impact on the lifetime of the battery. If the headset is idle for more than 20 minutes, it will automatically turn off in order to conserve battery. If a phone call comes in and you wish to connect through the headset, simply turn the headset back on immediately when the phone rings, wait for the Bluetooth connection to reestablish, and press the multi-function wheel once to connect the call.

Do not expose your headset to extreme temperatures, drop the headset, or expose your headset to moisture as doing so could damage the headset.

Warranty

Your headset is covered by a 1 year manufacturer warranty through Blue Tiger. This is a limited warranty covering electronic parts failure due to manufacturer defects and does not include failure due to normal wear or if the product has been used in any way not advised by Blue Tiger as disclosed in this user manual.

Details can be found at www.bluetigerusa.com or by calling Blue Tiger Support at 1-800-935-1165.